

Aide-mémoire
Quick reference guide

CONNEXITY

M520

M520N

M640



CONNEXITY

EADS
TELECOM

Calls

Calling an external number..... **0 + N°**

Calling an internal extension..... **N°**

Calling an attendant..... **9**
(or **Comm** **-->** **Operator**)

Automatic redialling of internal extension..... **Redial**
(if the number is busy or does not answer).
When the called extension hangs up, your extension rings.

If the number is busy or does not answer,
storing the number for redial..... **SAVE REPEAT**

To redial this number..... **SAVE REPEAT**

To cancel the storing..... **#79** or
Funct **Feature** **→** **Memory** **Store** **Cancel**

Transferring a communication
to an internal extension..... **R + N° +**

Simultaneous calls

In communication, when an external party is trying to reach you, you hear a beep.

Answering the call..... **Wait**
The first party is placed on hold.

You are in communication with the first party.
Calling a second party..... **Comm** **N°**
The first party is placed on hold.

Switching from one party to the other..... **Shuttle**
During the conversation with one party,
the other is placed on hold.

Releasing one party..... **Recover**
You are connected with the other party.

Three-way conference

You are in communication with one party and the other is placed on hold.

Establishing a three-way conference..... **Conf**

Leaving and transferring the call..... **Transf**
The two parties are connected
(except if the two parties are external calls).

Appels

0 + N° Appel d'un numéro externe

N° Appel d'un numéro interne

9 Appel du standard
(ou **Comm** **-->** **Standard**)

Rappel Rappel automatique d'un numéro interne
(en cas d'occupation ou de non réponse).
Votre poste sonnera au raccrochage de votre correspondant.

STOCKAGE REEMISSION En cas d'occupation ou de non réponse,
enregistrement du N° pour le ré-émettre

STOCKAGE REEMISSION Rappel du numéro

#79 ou Annulation de l'enregistrement
Service **Faculté** **→** **Mémoire** **Stockage** **Annul**

R + N° + Transfert d'une communication
vers un poste interne

Appels simultanés

En cours de communication,
si un appel externe arrive, émission d'un bip.

Attente Consultation de l'appel
Le 1^{er} correspondant est mis en attente.

Vous êtes en ligne avec un 1^{er} correspondant.
Comm **N°** Appel d'un 2^e correspondant
Le 1^{er} correspondant est mis en attente.

Alternat Passage d'un correspondant à l'autre
Pendant la conversation avec l'un des
correspondants, l'autre est mis en attente.

Reprise Libération d'un correspondant
Vous restez en communication avec l'autre correspondant.

Conférence à 3

Vous êtes en communication avec un
correspondant et un second est en attente.

Conf Etablissement d'une conférence à trois

Transf Fin avec transfert de la communication
Les deux correspondants restent en communication
(sauf si les deux correspondants sont externes).

Call forwarding

Accessing to call forwarding service

Funct **Feature** **Forward**

Then, selecting the call forwarding type

Delayed or **Busy** or **Immed.**

(on delayed call, on busy call or immediately)

Then, selecting the origin of calls

All or **Extern** or **Intern**

(All origins, external calls or internal calls)

To another set

According to user's class of service

Extens **N°** **Enter** 

or to voice mail

If you have a voice mailbox

V.Mail 

Cancelling any call forwarding

Funct **Feature** **Forward** **Cancel** 

Diverting a call

To an internal extension

while the phone is ringing..... **Divert** **N°**

Call pick up

Picking up a call meant for a

hunt group..... **Pick-up** **Group**

Picking up a call meant for an extension of another

group..... **Pick-up** **Poste** **N°**

Picking up a call on common ringing

Pick-up **Comm.Bell**

Appointment reminder

Programming an appointment

Funct **Feature** **Alarm** **Activ.**

...hhmm in 24-hour format (for example 6.30 pm is 1830)

Enter 

Cancelling an appointment

Funct **Feature** **Alarm** **Cancel** 

Renvoi d'appels

Accès au service renvoi

Service **Faculté** **Renvoi**

Puis, choix du type de renvoi

Différé ou **Occupé** ou **Immédiat**

(en cas de non réponse, sur occupation ou immédiat)

Puis, choix de l'origine des appels

Toutes ou **Ext** ou **Int**

(Toutes origines, appels internes ou appels externes)

Vers un autre poste

Si le poste en a le droit

Poste **N°** **Envoi** 

ou vers la messagerie vocale

Si la boîte vocale existe

MVocale 

Annulation d'un renvoi

Service **Faculté** **Renvoi** **Annul** 

Déviation d'un appel

Vers un numéro interne

Dévier **N°**.....lorsque le poste sonne

Interception d'appels

Interception d'un appel destiné à un poste

Recup **Groupe**.....de votre groupe

Interception d'un appel destiné à un poste

Recup **Poste** **N°**.....d'un autre groupe

Interception d'un appel sur sonnerie générale

Recup **Son.gen**

Rappel de rendez-vous

Programmation d'un rendez-vous

Service **Faculté** **Agenda** **Activ.**

hhmm (par exemple, 1830 correspond à 18H30).....

Envoi 

Annulation d'un rendez-vous

Service **Faculté** **Agenda** **Annul** 

Abbreviated numbers

Those are the system directories, independent of numbers you can store in your phone.

Personal directory

You can store in 10 abbreviated numbers (0 to 9) the phone numbers (N°) of your favorite correspondants.

Accessing directory..... **Funct** **Feature** **Abbrev#**

Storing an abbreviated number
..... **Activ.** **N°** **Enter**

Making a call using abbreviated numbers
..... **DIRECTORY** + **(0 - 9)**

Canceling an abbreviated number
Funct **Feature** **Abbrev#** (**More**) **Cancel**

General directory

Contact your administrator to have the list of abbreviated numbers memorized (nnn) in the general directory.

Calling using abbreviated numbers..... * + **3nnn** or
.... **Comm** **→** **→** **Other** **Abbrev#** + nnn

Set locking

Programming a personal password
..... **Funct** **Feature** **Passwd** **Modify**

Password (in four digits format, 0000 by default) **Enter**

New password **Enter** **New password** **Enter**

Locking your set
Funct **Feature** **→** **Lock** **Modify**

Unlocking your set..... **Funct** **Feature**
→ **Lock** **Modify** **Password** **Enter**

This document shows the functions available from your phone associated with a system of M6500 IP PBX and Succession 6500 ranges.

Numéros abrégés

Il s'agit des répertoires enregistrés dans le système, indépendants du répertoire qui peut exister sur votre poste.

Répertoire personnel

Vous disposez de 10 numéros abrégés (0 à 9) pour enregistrer les numéros (N°) de vos correspondants privilégiés.

Service **Faculté** **Repert** Accès au répertoire

Activ. **N°** **Envoi** Enregistrement d'un numéro abrégé

REPERTOIRE + **(0 - 9)** Appel d'un numéro abrégé

Service **Faculté** **Repert** (**Suite**) **Annul** Annulation d'un numéro abrégé

Répertoire collectif

Consultez l'exploitant de votre installation pour avoir la liste des numéros abrégés (xxx) du répertoire collectif.

* + **3XXX** ou..... Appel d'un numéro abrégé
Comm **→** **→** **Autre** **N° Abrg** + **XXX**....

Verrouillage poste

Programmation d'un code personnel
Service **Faculté** **Code** **Modif**

Code (4 chiffres, par défaut 0000) **Envoi**

Nouv. code **Envoi** **Nouv. code** **Envoi**

Service **Faculté** **→** **Verrou** **Modif** Verrouillage de votre poste

Service **Faculté** Déverrouillage de votre poste
→ **Verrou** **Modif** **Code** **Envoi**

Ce document vous présente les fonctions accessibles depuis votre poste, installé avec un système des gammes M6500 IP PBX et Succession 6500.

PS8145XAA02 - 01/02

Copyright© 2001 EADS Defence and Security Networks.

Ce document ne peut être considéré comme contractuel. Les renseignements y figurant sont donnés à titre indicatif et peuvent être modifiés sans avis préalable, reproduction interdite. Connexity est une marque déposée de EADS Defence and Security Networks. EADS est une marque déposée de EADS N.V. Succession est une marque déposée de Nortel Networks.

All rights reserved. Information subject to change without notice. EADS Defence and Security Networks reserves the right to make changes without notice, in equipment design as engineering or manufacturing consideration may warrant. Connexity is a registered trademark of EADS Defence and Security Networks. EADS is a trademark of EADS N.V. Succession is a trademark of Nortel Networks.

EADS Defence and Security Networks

Rue J.P. Timbaud - BP 26

78392 Bois d'Arcy Cedex - France

Tél : 33 (0)1 34 60 80 20

Fax : 33 (0)1 34 60 88 21

www.eads-telecom.com